



EVO-1168

EVO Chromoly C-Pillar Crossbar



Bill of Materials

Part number	EVO- Description	Quantity
EVO-12184	EVO-Chromoly C Pillar Crossbar	1
EVO-770065	EVO- C Pillar Crossbar Hardware	1

Before beginning install, it is recommended to remove the hard top from your vehicle to following the owner's manual instructions.

1. Unzip the fabric covering the rear factory c-pillar crossbar.
2. Remove the dome light and foam padding. These are held in with panel clips. A panel clip tool or similar tool is recommended for removal.
3. Remove wiring harness from factory cross bar, clipped in 3 places.



Note: If you have already installed the EVO MFG Chromoly Sport Cage Rear Bar, you will need to unbolt it as well

4. Use a 13mm socket to unbolt the cross bar. It is held in by 8 bolts, 2 on the top and 2 on the bottom of each corner.



5. Install the EVO MFG Chromoly C-Pillar Cross Bar. Reuse the factory bolts on the top, threading them back into the factory tubes. On the bottom, thread the 4 supplied M8 bolts, washers and nuts through the factory bolt holes. With all 8 bolts threaded, use a 13mm wrench, 13mm socket and extension to tighten these.
6. If you have not yet installed the Rear Bar, follow those instructions at this time. If you have already installed the Rear Bar, bolt it back onto the Cross Bar at this point



7. Reinstall the foam padding, dome light and wiring harness and zip the fabric back up.

