



EVO-1169

## EVO Sport Cage Grab Handles



### Bill of Materials

Part number	EVO-1169 Description	Quantity
EVO-12186	EVO Grab Handle Driver	1
EVO-12187	EVO Grab Handle Passenger	1
EVO-770069	Grab Handle Hardware Pack	1

**Note:** These grab handles install on EVO MFG Chromoly Sport Cages, after the Sport Cage is installed.

**Note:** Grab handles are intended for entering and exiting vehicle only and not for holding onto while the vehicle is in motion.

1. After your sport cage has been installed, hold the grab handle in place against the A Pillar and Upper Cross Bar, as shown.



2. Keeping the grab handle positioned, mark the holes to be drilled.



3. Double check your marks. When you are sure of your marks, center-punch them and pilot drill.
4. Open each hole up to 1/4".
5. Use a supplied button head cap screw, washers and, a standard locknut to loosely fasten the grab handle to the top crossbar.
6. Use the remaining button head cap screw, and washers with the supplied locking wing nut to loosely fasten the grab handle to the A-Pillar. Note that the wing nut goes on the inside and can be accessed through the hole on the side of the A-Pillar.
7. With all hardware threaded, use a 5/32 Allen wrench and 7/16 wrench to tighten. Note, the wing nut will bind against a gusset on the inside of the A-Pillar allowing the screw to tighten.